

## Astianpesukoneen puhdistus ja käyttö

### Puhdistus

- Tarkista säännöllisesti luukun tiivisteiden puhtaus ja pyyhi tarvittaessa kostealla sienellä tai rievulla.
- Pese kone tyhjänä kuukauden välein astianpesukoneen puhdistusaineella tai sitruunahapolla.
  - Puhdistusaineella tai sitruunahapolla pestään tyhjä kone kuumalla ohjelmalla.  
(sitruunahappoa annostellaan pesuainelokeroon 2-4 ruokalusikallista)
  - Kone tulee pysäyttää ennen kuivausohjelmaa.
  - Pese kone vielä tyhjänä tavallisella konetiskiaineella.
- Astianpesukoneen pohjasiivilä on hyvä irrottaa parin viikon välein, pestä siivilät ja siivilän alla oleva pohja-allas hyvin.

Pohjasiivilä irtoaa usein kääntämällä vastapäivään ja nostamalla ylös. (kuva)

### Käyttö

- Asettele astiat koneeseen isoimmista ruoantähteistä puhdistettuina.
- Katso, että astiat eivät ole painuneina toisiaan vasten.
- Muoviastiat on syytä pestä yläkorissa.
- Huolehdi että astiat on aseteltu niin etteivät pääse kääntymään pesun aikana.
- On suositeltavaa käyttää esipesuohjelmaa
- Huom! Kaikki astiat eivät kestä konepesua mm. alumiini, hopea, kupari, valurauta, ohuet muovikannet, kertakäyttöastiat...
- Astianpesukoneessa ei suositella puulastojen ja -leikkuulautojen pesua.
- Koristeellisista astioista voi koristukset haalistua tai irrota.
- **Älä jätä konetta valvomatta päälle!**
- Muista **aina** sulkea astianpesukoneen vesihana käytön jälkeen!
- Älä irrota astianpesukoneen sähköjohtoa seinästä (vuototurvajärjestelmä kytkeytyy pois päältä).



## Cleaning and using the dishwasher

### Cleaning

- Regularly check that the hatch seals are clean and in good condition. Wipe with a damp sponge or a rag if necessary.
- Wash the machine empty every month with dishwashers detergent or citric acid.
  - Use dishwashers detergent or citric acid and wash the empty machine with a hot program.  
(dispense 2-4 tablespoons of citric acid into the detergent compartment)
  - The machine must be stopped before the drying program.
  - Wash the machine again when it is still empty with a regular dishwasher detergent.
- It is good to remove the bottom strainer of the dishwasher every couple of weeks, wash the strainers and the bottom basin under the strainer well.

The bottom strainer often comes off by turning it counterclockwise and lifting it up. (picture)

### Use

- Place the dishes in the machine, cleaned of the largest food residues.
- Make sure that the dishes are not pressed against each other.
- Plastic containers should be washed in the upper basket.
- Make sure that the dishes are arranged so that they cannot turn during washing.
- It is recommended to use a pre-wash program
- Note! Not all dishes can be machine washed, e.g. aluminum, silver, copper, cast iron, thin plastic lids, disposable containers...
- It is not recommended to wash wooden spatulas and cutting boards in the dishwasher.
- Decorations on decorative dishes may fade or come off.
- **Do not leave the machine unattended!**
- **Always** remember to close the water tap of the dishwasher after use!
- Do not disconnect the dishwasher's electrical cord from the wall (the leakage protection system will be switched off).

